

Attachment, Hinge/Slider, Symmetry, and Sub-Surfaces


Rob McDonald




Attach Point

Every component is attached to (or placed in) the model by locating its attach point and positioning the component relative to that point

Attach Point, only shown when selected. (new in v3.9.0)





Axis Orientation RGB - XYZ






Attach to Parent (Comp)








Attach to Parent (UW)




U,W coordinates run [0,1] along surface

'UW' attaches to parent's surface





Rel vs. Abs



Attached components <u>always</u> move when their parent moves.


'Rel' sets the position/rotation relative to the attach point.

'Abs' sets the position/rotation in global coordinates.

When 'Rel' is selected, changing attachment moves component.

When 'Abs' is selected, component stationary as attachment changes (sometimes confusing).

Changing between 'Abs' and 'Rel' can be very powerful.






Blank

'Blank' components are a way to insert a new coordinate system.

Useful for positioning, mass properties, and grouping.

Blank shown as feature line or when selected

Attach Point only shown





Hinge (and/or Slider) (new v3.9.0)

'Hinge' components are a way to add simple motion to a model.

Children of 'Hinge' components are *forced* attached.

Hinge Fixed Side shown as feature line or when selected

Hinge Motion Side shown as feature line or when selected

Attach Point only shown when selected.




Forced attachment indicated by

in browser




Hinge Motion Control






Hinge Orientation






Example






Symmetry


Components can be symmetric about any plane (XY, XZ, YZ) or axis (X, Y, Z) of any ancestor attach point or object.







SubSurfaces



Subsurfaces are rectangles, ellipses, or lines defined in (U, W) coords on a surface.

> They can represent are honored by CompGeom, CFDMesh, and DegenGeom.

They can be used to model inlet/outlet BC's, control surfaces, material properties, etc.

Questions?

Practice

